

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use
 CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer
 Date of last update: 19.03.08

Agfa

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
ePhoto 1280	U-BXP			
ePhoto 1680	D-MAV			
ePhoto 780c	D-AM			
ePhoto CL18	D-MM			
ePhoto CL20	D-MM			
ePhoto CL 30	D-MM			
ePhoto CL 34				
ePhoto CL 50	D-AM			

analog

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
Other 35 mm compact	U-AM			
Other 35 mm compact	U-AMZ			
Other 35 mm compact	U-MM			
Other APS compact	U-AM			
Other APS compact	U-AMZ			
Other APS compact	U-MM			

Aiptek

all models

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
all models				

Bronica

all models

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
all models				

Canon

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
Digital ELPH				
EOS 10D	U-AXP			
EOS 10D	U-AXP100			
EOS 1D	U-BXP			
EOS 1D	U-BXP100			
EOS 1D Mark II	U-BXP			
EOS 1D Mark II	U-BXP100			
EOS 1D Mark III	U-BXP			
EOS 1D Mark III	U-BXP100			
EOS 1D Mark II N	U-BXP			
EOS 1D Mark II N	U-BXP100			
EOS 1Ds	U-BXP			
EOS 1Ds	U-BXP100			
EOS 1Ds Mark II	U-BXP			
EOS 1Ds Mark II	U-BXP100			
EOS 1Ds Mark III	U-BXP			
EOS 1Ds Mark III	U-BXP100			
EOS 20D	U-AXP			
EOS 20D	U-AXP100			
EOS 300D	U-AXP			
EOS 300D	U-AXP100			
EOS 30D	U-AXP			
EOS 30D	U-AXP100			
EOS 350D	U-A			
EOS 350D	U-AX			
EOS 350D	U-AXP			
EOS 350D	U-AXP100			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
EOS 350D	U-AZ			
EOS 400D	U-A			
EOS 400D	U-AX			
EOS 400D	U-AXP			
EOS 400D	U-AXP100			
EOS 400D	U-AZ			
EOS 40D	U-AXP			
EOS 40D	U-AXP100			
EOS 40D	U-B			
EOS 450D	U-A			
EOS 450D	U-AX			
EOS 450D	U-AXP			
EOS 450D	U-AXP100			
EOS 450D	U-AZ			
EOS 5D	U-BXP			
EOS 5D	U-BXP100			
EOS D2000	D-KCS			
EOS D30	U-AXP			
EOS D30	U-AXP100			
EOS D60	U-AXP			
EOS D60	U-AXP100			
EOS Digital Rebel	U-AXP			
EOS Digital Rebel	U-AXP100			
EOS Digital Rebel XSi	U-A			
EOS Digital Rebel XSi	U-AX			
EOS Digital Rebel XSi	U-AXP			
EOS Digital Rebel XT	U-A			
EOS Digital Rebel XT	U-AX			
EOS Digital Rebel XT	U-AXP			
EOS Digital Rebel XT	U-AXP100			
EOS Digital Rebel XT	U-AZ			
EOS Digital Rebel XTi	U-A			
EOS Digital Rebel XTi	U-AX			
EOS Digital Rebel XTi	U-AXP			
EOS Digital Rebel XTi	U-AXP100			
EOS Digital Rebel XTi	U-AZ			
EOS Kiss Digital X	U-A			
EOS Kiss Digital X	U-AX			
EOS Kiss Digital X	U-AXP			
EOS Kiss Digital X	U-AXP100			
EOS Kiss Digital X	U-AZ			
EOS Kiss X2	U-A			
EOS Kiss X2	U-AX			
EOS Kiss X2	U-AXP			
EOS Kiss X2	U-AXP100			
EOS Kiss X2	U-AZ			
Ixus 55	D-LI2			
Ixus 60	D-LI2			
Ixus 65	D-LI2			
Ixus 70	D-LI2			
Ixus 75	D-LI2			
Ixus 750	D-SW			
Ixus 80	D-LI2			
Ixus 800 IS	D-SW			
Ixus 850 IS	D-SW			
Ixus 860 IS	D-SW			
Ixus 900 Ti	D-SW			
Ixus 950 IS	D-SW			
Ixus 960 IS	D-SW			
IXY Digital 10	D-LI2			
IXY Digital 1000	D-SW			
IXY Digital 2000is	D-SW			
IXY Digital 20is	D-LI2			
IXY Digital 30	D-SW			
IXY Digital 30a	D-SW			
IXY Digital 320	D-SW			
IXY Digital 450	D-SW			
IXY Digital 50	D-SW			
IXY Digital 500	D-SW			
IXY Digital 55	D-SW			
IXY Digital 60	D-SW			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update: 19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
IXY Digital 600	D-SW			
IXY Digital 70	D-SW			
IXY Digital 700	D-SW			
IXY Digital 80	D-SW			
IXY Digital 800	D-SW			
IXY Digital 810is	D-SW			
IXY Digital 90	D-LI2			
IXY Digital 900	D-SW			
IXY Digital 910 is	D-SW			
IXY Digital L				
IXY Digital L2				
IXY Digital L3				
IXY Digital L4				
IXY Digital Wireless				
other Digital Ixus				
other IXY Digital not listed				
PowerShot A10	D-AM			
PowerShot A100	D-MM			
PowerShot A20	D-AM			
PowerShot A200	D-MM			
PowerShot A30	D-AM			
PowerShot A300	D-MM			
PowerShot A310	D-CP1			
PowerShot A40	D-AM			
PowerShot A400	D-CP1			
PowerShot A410	D-CP2			
PowerShot A420	D-CP2			
PowerShot A430	D-CP2			
PowerShot A460	D-CP2			
PowerShot A470	D-CP2			
PowerShot A5	D-MM			
PowerShot A50	D-MM			
PowerShot A510	D-SC			
PowerShot A520	D-SC			
PowerShot A530	D-SC			
PowerShot A540	D-SC			
PowerShot A550	D-SC			
PowerShot A560	D-SC			
PowerShot A570 IS	D-SC			
PowerShot A580	D-SC			
PowerShot A590	D-SC			
PowerShot A5 Zoom	D-MM			
PowerShot A60	D-SC			
PowerShot A610	D-SC			
PowerShot A620	D-SC			
PowerShot A630	D-SC			
PowerShot A640	D-SC			
PowerShot A650	D-SC			
PowerShot A70	D-SC			
PowerShot A700	D-SC			
PowerShot A710	D-SC			
PowerShot A720 IS	D-SC			
PowerShot A75	D-SC			
PowerShot A80	D-SC			
PowerShot A85	D-SC			
PowerShot A95	D-SC			
PowerShot G1	D-A	C-A58		
PowerShot G1	D-AX	C-A58		
PowerShot G1	D-CG1			
PowerShot G2	D-A	C-A58		
PowerShot G2	D-AX	C-A58		
PowerShot G2	D-CG1			
PowerShot G3	D-A	C-A58		
PowerShot G3	D-AX	C-A58		
PowerShot G3	D-CG3			
PowerShot G5	D-A	C-A58		
PowerShot G5	D-AX	C-A58		
PowerShot G5	D-CG3			
PowerShot G6	D-A	C-A58		
PowerShot G6	D-AX	C-A58		

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
PowerShot G6	D-CG6			
PowerShot G7	D-A	C-A58		
PowerShot G7	D-AX	C-A58		
PowerShot G7	D-CG7			
PowerShot G9	D-A	C-A58		
PowerShot G9	D-AX	C-A58		
PowerShot G9	D-CG7			
PowerShot Pro1	D-A			
PowerShot Pro70				
PowerShot Pro90				
PowerShot S10	D-MM			
PowerShot S 100				
PowerShot S 110				
PowerShot S1 IS	D-A	C-A58		
PowerShot S20	D-MM			
PowerShot S 200				
PowerShot S 230				
PowerShot S2 IS	D-A	C-A58		
PowerShot S30	D-AM			
PowerShot S 300				
PowerShot S3 IS	D-A	C-A58		
PowerShot S40	D-AM			
PowerShot S400	D-AM			
PowerShot S410	D-AM			
PowerShot S45	D-AM			
PowerShot S50	D-MM			
PowerShot S5 IS	D-A	C-A58		
PowerShot S5 IS	D-AX	C-A58		
PowerShot S60	D-MM			
PowerShot S70	D-MM			
PowerShot S80	D-CP2			
PowerShot SD1000	D-LI2			
PowerShot SD 1100				
PowerShot SD550	D-SW			
PowerShot SD600	D-LI2			
PowerShot SD630	D-LI2			
PowerShot SD750	D-LI2			
PowerShot SD800	D-SW			
PowerShot SD 850				
PowerShot SD 870				
PowerShot SD900	D-SW			
PowerShot SD 950				
PowerShot SD 960				
PowerShot TX1				

analog

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
A-1	U-F			
A-1	U-FGM			
A-1	U-FX			
A-1	U-FXP			
AE-1	U-F			
AE-1	U-FGM			
AE-1	U-FX			
AE-1	U-FXP			
AL-1	U-F			
AL-1	U-FGM			
AL-1	U-FX			
AL-1	U-FXP			
AT-1	U-F			
AT-1	U-FGM			
AT-1	U-FX			
AT-1	U-FXP			
AV-1	U-F			
AV-1	U-FGM			
AV-1	U-FX			
AV-1	U-FXP			
EF Series	U-F			
EF Series	U-FGM			
EF Series	U-FX			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
EF Series	U-FXP			
ELPH APS				
EOS 1	U-AXP			
EOS 100	U-A			
EOS 100	U-AX			
EOS 100	U-AXP			
EOS 100	U-AXP100			
EOS 100	U-AZ			
EOS 10s	U-A			
EOS 10s	U-AX			
EOS 10s	U-AXP			
EOS 10s	U-AXP100			
EOS 10s	U-AZ			
EOS 1n	U-AXP			
EOS 1n RS	U-AXP			
EOS 1v	U-AXP			
EOS 3	U-AXP			
EOS 30	U-A			
EOS 30	U-AX			
EOS 30	U-AXP			
EOS 30	U-AXP100			
EOS 30	U-AZ			
EOS 300	U-A			
EOS 300	U-AX			
EOS 300	U-AXP			
EOS 300	U-AXP100			
EOS 300	U-AZ			
EOS 300V	U-A			
EOS 300V	U-AX			
EOS 300V	U-AXP			
EOS 300V	U-AXP100			
EOS 300V	U-AZ			
EOS 50	U-A			
EOS 50	U-AX			
EOS 50	U-AXP			
EOS 50	U-AXP100			
EOS 50	U-AZ			
EOS 500	U-A			
EOS 500	U-AX			
EOS 500	U-AXP			
EOS 500	U-AXP100			
EOS 500	U-AZ			
EOS 500N	U-A			
EOS 500N	U-AX			
EOS 500N	U-AXP			
EOS 500N	U-AXP100			
EOS 500N	U-AZ			
EOS 620	U-A			
EOS 620	U-AX			
EOS 620	U-AXP			
EOS 620	U-AXP100			
EOS 620	U-AZ			
EOS 630	U-A			
EOS 630	U-AX			
EOS 630	U-AXP			
EOS 630	U-AXP100			
EOS 630	U-AZ			
EOS 650	U-A			
EOS 650	U-AX			
EOS 650	U-AXP			
EOS 650	U-AXP100			
EOS 650	U-AZ			
EOS 66QD	U-A			
EOS 66QD	U-AX			
EOS 66QD	U-AXP			
EOS 66QD	U-AXP100			
EOS 66QD	U-AZ			
EOS A2	U-A			
EOS A2	U-AX			
EOS A2	U-AXP			
EOS A2	U-AXP100			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
EOS A2	U-AZ			
EOS Elan	U-A			
EOS Elan	U-AX			
EOS Elan	U-AXP			
EOS Elan	U-AXP100			
EOS Elan	U-AZ			
EOS Elan 2	U-A			
EOS Elan 2	U-AX			
EOS Elan 2	U-AXP			
EOS Elan 2	U-AXP100			
EOS Elan 2	U-AZ			
EOS Elan 7	U-A			
EOS Elan 7	U-AX			
EOS Elan 7	U-AXP			
EOS Elan 7	U-AXP100			
EOS Elan 7	U-AZ			
EOS Elan 7e	U-A			
EOS Elan 7e	U-AX			
EOS Elan 7e	U-AXP			
EOS Elan 7e	U-AXP100			
EOS Elan 7e	U-AZ			
EOS Elan 7n	U-A			
EOS Elan 7n	U-AX			
EOS Elan 7n	U-AXP			
EOS Elan 7n	U-AXP100			
EOS Elan 7n	U-AZ			
EOS Elan 7ne	U-A			
EOS Elan 7ne	U-AX			
EOS Elan 7ne	U-AXP			
EOS Elan 7ne	U-AXP100			
EOS Elan 7ne	U-AZ			
EOS IX	U-A			
EOS IX	U-AX			
EOS IX	U-AXP			
EOS IX	U-AXP100			
EOS IX	U-AZ			
EOS IX 7	U-A			
EOS IX 7	U-AX			
EOS IX 7	U-AXP			
EOS IX 7	U-AXP100			
EOS IX 7	U-AZ			
EOS IX Lite	U-A			
EOS IX Lite	U-AX			
EOS IX Lite	U-AXP			
EOS IX Lite	U-AXP100			
EOS IX Lite	U-AZ			
EOS Rebel	U-A			
EOS Rebel	U-AX			
EOS Rebel	U-AXP			
EOS Rebel	U-AXP100			
EOS Rebel	U-AZ			
EOS Rebel 2000	U-A			
EOS Rebel 2000	U-AX			
EOS Rebel 2000	U-AXP			
EOS Rebel 2000	U-AXP100			
EOS Rebel 2000	U-AZ			
EOS Rebel G	U-A			
EOS Rebel G	U-AX			
EOS Rebel G	U-AXP			
EOS Rebel G	U-AXP100			
EOS Rebel G	U-AZ			
EOS Rebel K2	U-A			
EOS Rebel K2	U-AX			
EOS Rebel K2	U-AXP			
EOS Rebel K2	U-AXP100			
EOS Rebel K2	U-AZ			
EOS Rebel S	U-A			
EOS Rebel S	U-AX			
EOS Rebel S	U-AXP			
EOS Rebel S	U-AXP100			
EOS Rebel S	U-AZ			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
EOS Rebel T2	U-A			
EOS Rebel T2	U-AX			
EOS Rebel T2	U-AXP			
EOS Rebel T2	U-AXP100			
EOS Rebel T2	U-AZ			
EOS Rebel Ti	U-A			
EOS Rebel Ti	U-AX			
EOS Rebel Ti	U-AXP			
EOS Rebel Ti	U-AXP100			
EOS Rebel Ti	U-AZ			
EOS RT	U-A			
EOS RT	U-AX			
EOS RT	U-AXP			
EOS RT	U-AXP100			
EOS RT	U-AZ			
F-1	U-F			
F-1	U-FGM			
F-1	U-FX			
F-1	U-FXP			
FTb	U-F			
FTb	U-FGM			
FTb	U-FX			
FTb	U-FXP			
FTbn	U-F			
FTbn	U-FGM			
FTbn	U-FX			
FTbn	U-FXP			
Ixus APS				
New F-1	U-F			
New F-1	U-FGM			
New F-1	U-FX			
New F-1	U-FXP			
Other 35 mm compact	U-AM			
Other 35 mm compact	U-AMZ			
Other 35 mm compact	U-MM			
Other APS compact	U-AM			
Other APS compact	U-AMZ			
Other APS compact	U-MM			
Sure Shot Series	U-AM			
Sure Shot Series	U-AMZ			
Sure Shot Series	U-MM			
T-50	U-F			
T-50	U-FGM			
T-50	U-FX			
T-50	U-FXP			
T-60	U-F			
T-60	U-FGM			
T-60	U-FX			
T-60	U-FXP			
T-70	U-F			
T-70	U-FGM			
T-70	U-FX			
T-70	U-FXP			
T-80	U-F			
T-80	U-FGM			
T-80	U-FX			
T-80	U-FXP			
T-90	U-F			
T-90	U-FGM			
T-90	U-FX			
T-90	U-FXP			
TLb	U-F			
TLb	U-FGM			
TLb	U-FX			
TLb	U-FXP			
TX	U-F			
TX	U-FGM			
TX	U-FX			
TX	U-FXP			

all models

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use
 CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer
 Date of last update: 19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
IXY APS				

Casio

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
Exilim EX-M1	D-LIM			
Exilim EX-M2	D-LIM			
Exilim EX-P505	D-A			
Exilim EX-P600	D-MM			
Exilim EX-P700	D-MM			
Exilim EX-S1	D-LIM			
Exilim EX-S10	D-LI3			
Exilim EX-S100	D-LI2			
Exilim EX-S2	D-LIM			
Exilim EX-S20	D-LIM			
Exilim EX-S500	D-LI3			
Exilim EX-S600	D-LI3			
Exilim EX-S770	D-LI3			
Exilim EX-S880	D-LI3			
Exilim EX-V7				
Exilim EX-Z10	D-LI2			
Exilim EX-Z100	D-LI2			
Exilim EX-Z1000	D-LI2			
Exilim EX-Z1050	D-LI2			
Exilim EX-Z1080	D-LI2			
Exilim EX-Z11	D-LI3			
Exilim EX-Z110	D-LI2			
Exilim EX-Z120	D-LI2			
Exilim EX-Z1200	D-LI2			
Exilim EX-Z3	D-LI2			
Exilim EX-Z30	D-LI2			
Exilim EX-Z4	D-LI2			
Exilim EX-Z40	D-LI2			
Exilim EX-Z5	D-LI2			
Exilim EX-Z50	D-LI2			
Exilim EX-Z500	D-LI2			
Exilim EX-Z55	D-LI2			
Exilim EX-Z60	D-LI2			
Exilim EX-Z600	D-LI2			
Exilim EX-Z65	D-LI3			
Exilim EX-Z70	D-LI2			
Exilim EX-Z700	D-LI2			
Exilim EX-Z75	D-LI3			
Exilim EX-Z750	D-LI2			
Exilim EX-Z77	D-LI3			
Exilim EX-Z80	D-LI2			
Exilim EX-Z850	D-LI2			
QV-10				
QV-2000 UX	D-AM			
QV-2300 UX	D-MM			
QV-2400 UX				
QV-2800 UX				
QV-2900 UX				
QV-3	D-MM			
QV-3000 UX	D-AM			
QV-3500	D-AM			
QV-4000	D-A			
QV-4000	D-AX			
QV-4000	D-CG3			
QV-5700	D-A			
QV-5700	D-AX			
QV-5700	D-CG3			
QV-8000 SX				
QV-R3	D-MM			
QV-R4	D-MM			
QV-R41	D-MM			
QV-R51	D-MM			
QV-R52	D-MM			
QV-R61	D-MM			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update: 19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
QV-R62	D-MM			

Epson

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
PC 3000z	D-CG3			
PC 3100z	D-CG3			
PC 650	D-AM			
PC 750z	D-AM			
PC 800	D-MM			
PC 850z				
PC L400	D-AM			

Exacta

all models

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
all models				

Fuji

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
Finepix 1300	D-MM			
Finepix 1400	D-AM			
Finepix 2300	D-AM			
Finepix 2400	D-AM			
Finepix 2600	D-AM			
Finepix 2800				
Finepix 30i				
Finepix 40i				
Finepix 4700				
Finepix 4800	D-FA			
Finepix 4900	D-A			
Finepix 4900	D-AX			
Finepix 6800	D-FA			
Finepix 6900	D-A			
Finepix 6900	D-AX			
Finepix A101	D-MM			
Finepix A120	D-MM			
Finepix A201	D-MM			
Finepix A202	D-MM			
Finepix A203	D-MM			
Finepix A204	D-MM			
Finepix A205S	D-MM			
Finepix A210	D-MM			
Finepix A303	D-MM			
Finepix A310	D-MM			
Finepix A330	D-MM			
Finepix A340	D-MM			
Finepix A345	D-MM			
Finepix A350	D-MM			
Finepix A400	D-SW			
Finepix A500	D-SW			
Finepix A510	D-SW			
Finepix A600	D-SW			
Finepix A610	D-SW			
Finepix A700	D-SW			
Finepix A800	D-SW			
Finepix A820	D-SW			
Finepix A825	D-SW			
Finepix A900	D-SW			
Finepix A920	D-SW			
Finepix Digital Q1				
Finepix DS330	D-CG1			
Finepix DS560	U-AXP			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
Finepix DS565	U-AXP			
Finepix E500	D-MM			
Finepix E510	D-MM			
Finepix E550	D-MM			
Finepix E900	D-MM			
Finepix F10	D-SW			
Finepix F100	D-SW			
Finepix F11	D-SW			
Finepix F20	D-SW			
Finepix F30	D-SW			
Finepix F31	D-SW			
Finepix F40	D-SW			
Finepix F401	D-MM			
Finepix F410	D-MM			
Finepix F420				
Finepix F440	D-MM			
Finepix F450	D-MM			
Finepix F455	D-CP1			
Finepix F460	D-MM			
Finepix F470	D-LI2			
Finepix F47 fd	D-LI2			
Finepix F480	D-LI2			
Finepix F50 fd	D-LI2			
Finepix F601	D-FA			
Finepix F610	D-FA			
Finepix F650	D-MM			
Finepix F700	D-MM			
Finepix F810	D-MM			
Finepix J10	D-MM			
Finepix J50	D-MM			
Finepix M603				
Finepix MX 1200	D-MM			
Finepix MX 1500	D-MM			
Finepix MX 1700				
Finepix MX 2700				
Finepix MX 2900	D-MX			
Finepix MX 600	D-AM			
Finepix S1000	D-A			
Finepix S1000	D-AX			
Finepix S100 FS	D-A			
Finepix S100 FS	D-AM			
Finepix S1 Pro	U-AXP			
Finepix S1 Pro	U-AXP100			
Finepix S20	D-A			
Finepix S20	D-AX			
Finepix S2 Pro	U-AXP			
Finepix S2 Pro	U-AXP100			
Finepix S304				
Finepix S3500	D-A			
Finepix S3 Pro	U-AXP			
Finepix S3 Pro	U-AXP100			
Finepix S5000	D-A			
Finepix S5500	D-A			
Finepix S5600	D-A			
Finepix S5700	D-A			
Finepix S5800	D-A			
Finepix S5 Pro	U-A			
Finepix S5 Pro	U-AX			
Finepix S5 Pro	U-AXP			
Finepix S5 Pro	U-AXP100			
Finepix S5 Pro	U-AZ			
Finepix S602	D-A			
Finepix S602	D-AX			
Finepix S6500	U-AXP			
Finepix S7000	D-A			
Finepix S7000	D-AX			
Finepix S8000 fd	D-A			
Finepix S8100				
Finepix S9500	D-A			
Finepix S9500	D-AX			
Finepix S9600	D-A			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update: 19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
Finepix S9600	D-AX			
Finepix V10	D-SW			
Finepix Z1				
Finepix Z100				
Finepix Z100 fd				
Finepix Z10 fd				
Finepix Z2				
Finepix Z20				
Finepix Z3				
Finepix Z5 fd				

analog

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
Other 35 mm compact	U-AM			
Other 35 mm compact	U-AMZ			
Other 35 mm compact	U-MM			
Other APS compact	U-AM			
Other APS compact	U-AMZ			
Other APS compact	U-MM			

GE

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
A 730	D-MM			
A 735	D-MM			
A 830	D-MM			
A 835	D-MM			
E 1030	D-MM			
E 1035	D-MM			
E 1040	D-MM			
E 1050	D-MM			
E 1235	D-MM			
E 1240	D-MM			
E 840	D-MM			
E 850	D-MM			
G 1				
G 2				
G 3				
X 1	D-A			
X 1	D-AX			
X 3	D-A			
X 3	D-AX			

Hasselblad

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
H System				

analog

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
500 Series				
900 Series				
V System				
XPAN				

HP/Hewlett-Packard

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
PhotoSmart 318				
PhotoSmart 320	D-MM			
PhotoSmart 435	D-AM			
PhotoSmart 618				
PhotoSmart 620	D-AM			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update: 19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
PhotoSmart 635	D-MM			
PhotoSmart 715				
PhotoSmart 720	D-AM			
PhotoSmart 735	D-AM			
PhotoSmart 812	D-MM			
PhotoSmart 850				
PhotoSmart 912				
PhotoSmart 935	D-MM			
PhotoSmart 945				
PhotoSmart C200	D-AM			
PhotoSmart C500	D-AM			
PhotoSmart E327				
PhotoSmart E337				
PhotoSmart E427	D-MM			
PhotoSmart M20				
PhotoSmart M22				
PhotoSmart M23				
PhotoSmart M305	D-CP1			
PhotoSmart M307	D-CP1			
PhotoSmart M407	D-CP2			
PhotoSmart M415	D-CP2			
PhotoSmart M417	D-CP2			
PhotoSmart M437	D-SW			
PhotoSmart M447	D-SW			
PhotoSmart M517	D-CP2			
PhotoSmart M525	D-MM			
PhotoSmart M527	D-MM			
PhotoSmart M537	D-SW			
PhotoSmart M627	D-MM			
PhotoSmart M637	D-SW			
PhotoSmart M737	D-SW			
PhotoSmart Mz67	D-SW			
PhotoSmart R507	D-MM			
PhotoSmart R607	D-SW			
PhotoSmart R707	D-MM			
PhotoSmart R717	D-MM			
PhotoSmart R727				
PhotoSmart R737	D-MM			
PhotoSmart R742	D-SW			
PhotoSmart R817	D-MM			
PhotoSmart R818	D-AM			
PhotoSmart R827				
PhotoSmart R827				
PhotoSmart R837				
PhotoSmart R847				
PhotoSmart R927	D-LI2			
PhotoSmart R927	D-SW			
PhotoSmart R937				
PhotoSmart R967	D-SW			

Jenoptik

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
all models				

Kodak

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
C613	D-SW			
DC5000				
DC-5000				
DCS 520	D-KCS			
DCS 560	D-KCS			
DCS 620	D-KCS			
DCS 720	D-KCS			
DCS 760	D-KCS			
DX3600				

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
DX-3600				
DX6490				
DX-6490				
EasyShare C300	D-AM			
EasyShare C300	D-MM			
EasyShare C310	D-AM			
EasyShare C310	D-MM			
EasyShare C330	D-MM			
EasyShare C340	D-MM			
EasyShare C360	D-AM			
EasyShare C360	D-SW			
EasyShare C433	D-SW			
EasyShare C503	D-SW			
EasyShare C530	D-MM			
EasyShare C533	D-SW			
EasyShare C643	D-SW			
EasyShare C653	D-SW			
EasyShare C663	D-SW			
EasyShare C743	D-SW			
EasyShare C875	D-CP2			
EasyShare CX4200	D-AM			
EasyShare CX4230	D-AM			
EasyShare CX4300	D-AM			
EasyShare CX6200	D-MM			
EasyShare CX6230	D-MM			
EasyShare CX6330	D-MM			
EasyShare CX7220	D-MM			
EasyShare CX7300	D-MM			
EasyShare CX7310	D-MM			
EasyShare CX7330	D-MM			
EasyShare CX7430	D-MM			
EasyShare CX7525	D-MM			
EasyShare CX7530	D-MM			
EasyShare DC20	D-MM			
EasyShare DC200	D-AM			
EasyShare DC210	D-AM			
EasyShare DC215	D-MM			
EasyShare DC220	D-KOD			
EasyShare DC240	D-AM			
EasyShare DC25	D-MM			
EasyShare DC260	D-KOD			
EasyShare DC265	D-KOD			
EasyShare DC280	D-AM			
EasyShare DC290	D-KOD			
EasyShare DC3200	D-MM			
EasyShare DC3400	D-AM			
EasyShare DC3800	D-MM			
EasyShare DC4800	D-AM			
EasyShare DX3215	D-AM			
EasyShare DX3500	D-AM			
EasyShare DX3700	D-AM			
EasyShare DX3900	D-AM			
EasyShare DX4330	D-AM			
EasyShare DX4530	D-AM			
EasyShare DX4900	D-AM			
EasyShare DX6340	D-AM			
EasyShare DX6440	D-AM			
EasyShare DX7440	D-AM			
EasyShare DX7590	D-A			
EasyShare DX7630	D-AM			
EasyShare LS633	D-CP1			
EasyShare LS743	D-CP1			
EasyShare LS753	D-CP1			
EasyShare LS755	D-SW			
Easy Share one	D-LI2			
EasyShare P712	D-A	C-A55		
EasyShare P712	D-AX	C-A55		
EasyShare P850	D-A	C-A55		
EasyShare P850	D-AX	C-A55		
EasyShare P880	D-A	C-A55		
EasyShare P880	D-AX	C-A55		

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
EasyShare V1003	D-LI2			
EasyShare V530	D-LI2			
EasyShare V530	D-LI2			
EasyShare V550	D-LI2			
EasyShare V603	D-LI2			
EasyShare V803	D-LI2			
EasyShare Z730	D-MM			
EasyShare Z740	D-A			
EasyShare Z7590	D-A			
M753	D-SW			
M853	D-SW			
M873	D-SW			
M883	D-SW			
V570				
V 570				
V610				
V 610				
V705				
V 705				
Z1275	D-SW			
Z610				
Z 610				
Z612				
Z 612				
Z650				
Z 650				
Z700				
Z 700				
Z710				
Z 710				
Z712				
Z 712				
Z760				
Z 760				
Z885	D-SW			
ZD710	D-A			

analog

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
Other 35 mm compact	U-AM			
Other 35 mm compact	U-AMZ			
Other 35 mm compact	U-MM			
Other APS compact	U-AM			
Other APS compact	U-AMZ			
Other APS compact	U-MM			

Konica

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
Revio C2				
Revio KD 200	D-MM			
Revio KD 220	D-AM			
Revio KD 300	D-MM			
Revio KD 310	D-MM			
Revio KD 400	D-MM			
Revio KD 410	D-MM			
Revio KD 420Z	D-MM			
Revio KD 500	D-MM			
Revio KD 510	D-MM			

analog

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
Other 35 mm compact	U-AM			
Other 35 mm compact	U-AMZ			
Other 35 mm compact	U-MM			
Other APS compact	U-AM			
Other APS compact	U-AMZ			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update: 19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
Other APS compact	U-MM			

KonicaMinolta

digital

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
Dimage 5	D-A			
Dimage 5	D-AX			
Dimage 7	D-A			
Dimage 7	D-AX			
Dimage 7Hi	D-A			
Dimage 7Hi	D-AX			
Dimage 7i	D-A			
Dimage 7i	D-AX			
Dimage A1	D-A			
Dimage A1	D-AX			
Dimage A2	D-A			
Dimage A2	D-AX			
Dimage A200	D-A			
Dimage A200	D-AX			
Dimage E201				
Dimage E203				
Dimage E223	D-AM			
Dimage E323	D-MM			
Dimage E40	D-LI2			
Dimage E50	D-LI2			
Dimage E500				
Dimage F100	D-CP1			
Dimage F200	D-CP1			
Dimage F300	D-CP1			
Dimage G400	D-MM			
Dimage G500	D-MM			
Dimage G530	D-MM			
Dimage G600	D-MM			
Dimage S304	D-CG1			
Dimage S404	D-CG1			
Dimage S414	D-CG1			
Dimage X-Series				
Dimage Z1	D-A	C-A52		
Dimage Z1	D-AX	C-A52		
Dimage Z10	D-A			
Dimage Z10	D-AX			
Dimage Z2	D-A	C-A52		
Dimage Z2	D-AX	C-A52		
Dimage Z20	D-A			
Dimage Z3	D-A			
Dimage Z3	D-AX			
Dimage Z5	D-A			
Dimage Z5	D-AX			
Dimage Z6	D-A	C-A52		
Dimage Z6	D-AX	C-A52		
Dynax 5D	U-A			
Dynax 5D	U-AX			
Dynax 5D	U-AXP			
Dynax 5D	U-AXP100			
Dynax 5D	U-AZ			
Dynax 7D	U-BXP			
Dynax 7D	U-BXP100			

Kyocera

digital

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
Finecam L3	D-CP1			
Finecam L30	D-CP1			
Finecam L4	D-CP1			
Finecam M400	D-A			
Finecam M410	D-A			
Finecam S3	D-MM			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update: 19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
Finecam S3L	D-MM			
Finecam S3X	D-MM			
Finecam S4	D-MM			
Finecam S5	D-MM			
Finecam tvS	D-AM			

Leica

digital

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
C-LUX 1	D-SC			
C-LUX 2	D-SW			
Digilux 1				
Digilux 2	U-F			
Digilux 2	U-FGM			
Digilux 2	U-FX			
Digilux 2	U-FXP			
Digilux 3				
D-LUX	D-CP1			
D-LUX 2	D-SC			
D-LUX 3	D-SC			
M8	U-F			
M8	U-FGM			
M8	U-FX			
M8	U-FXP			
V-LUX 1				

analog

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
M Series	U-F			
M Series	U-FGM			
M Series	U-FX			
M Series	U-FXP			
Other 35 mm compact	U-AM			
Other 35 mm compact	U-AMZ			
Other 35 mm compact	U-MM			
Other APS compact	U-AM			
Other APS compact	U-AMZ			
Other APS compact	U-MM			
R Series	U-F			
R Series	U-FGM			
R Series	U-FX			
R Series	U-FXP			

Linhof

all models

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
all models				

Mamiya

all models

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
all models				

Minolta

digital

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
Dimage E201				
Dimage I				
Dimage XI				

analog

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
Alpha Series	U-A			
Alpha Series	U-AX			
Alpha Series	U-AXP			
Alpha Series	U-AXP100			
Alpha Series	U-AZ			
Dynax Series	U-A			
Dynax Series	U-AX			
Dynax Series	U-AXP			
Dynax Series	U-AXP100			
Dynax Series	U-AZ			
Maxxum Series	U-A			
Maxxum Series	U-AX			
Maxxum Series	U-AXP			
Maxxum Series	U-AXP100			
Maxxum Series	U-AZ			
Other 35 mm compact	U-AM			
Other 35 mm compact	U-AMZ			
Other 35 mm compact	U-MM			
Other APS compact	U-AM			
Other APS compact	U-AMZ			
Other APS compact	U-MM			
X-300	U-F			
X-300	U-FGM			
X-300	U-FX			
X-300	U-FXP			
X-300s	U-F			
X-300s	U-FGM			
X-300s	U-FX			
X-300s	U-FXP			
X-370	U-F			
X-370	U-FGM			
X-370	U-FX			
X-370	U-FXP			
X-370M	U-F			
X-370M	U-FGM			
X-370M	U-FX			
X-370M	U-FXP			
X-370s	U-F			
X-370s	U-FGM			
X-370s	U-FX			
X-370s	U-FXP			
X-500	U-F			
X-500	U-FGM			
X-500	U-FX			
X-500	U-FXP			
X-570	U-F			
X-570	U-FGM			
X-570	U-FX			
X-570	U-FXP			
X-600	U-F			
X-600	U-FGM			
X-600	U-FX			
X-600	U-FXP			
X-7	U-F			
X-7	U-FGM			
X-7	U-FX			
X-7	U-FXP			
X-70	U-F			
X-70	U-FGM			
X-70	U-FX			
X-70	U-FXP			
X-700	U-F			
X-700	U-FGM			
X-700	U-FX			
X-700	U-FXP			
X-7A	U-F			
X-7A	U-FGM			
X-7A	U-FX			
X-7A	U-FXP			
X-9	U-F			
X-9	U-FGM			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
X-9	U-FX			
X-9	U-FXP			
XG-A	U-F			
XG-A	U-FGM			
XG-A	U-FX			
XG-A	U-FXP			

Minox

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
DC 1011	D-SW			
DC 1311	D-MM			
DC 2111				
DC 2122				
DC 2133	D-MM			
DC 3311				
DC 4011	D-MM			
DC 4211	D-SW			
DC 5011	D-SW			
DC 5211	D-SW			
DC 5222	D-SW			
DC 6011	D-SW			
DC 6211	D-SW			
DC 6311	D-SW			
DC 7011	D-MM			
DC 8111	D-SW			
DC 8122	D-SW			
DD1				
DD 200	D-MM			
DM 1				

analog

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
35 EL				
35 GL				
35 GT				
35 ML				
8x11 Camera AX				
8x11 Camera CLX				
8x11 Camera EC				
8x11 Camera ECX				
8x11 Camera LX				
8x11 Camera MX				
8x11 Camera TLX				
CD 128	D-MM			
CD 140	D-MM			
CD 150	D-MM			
CD 155	D-MM			
GT-X				

Nikon

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
Coolpix 100				
Coolpix 2000	D-AM			
Coolpix 2100	D-AM			
Coolpix 2200	D-AM			
Coolpix 2500	D-AM			
Coolpix 300				
Coolpix 3100	D-AM			
Coolpix 3200	D-AM			
Coolpix 3500	D-AM			
Coolpix 3700	D-CP2			
Coolpix 4100	D-AM			
Coolpix 4200	D-AM			
Coolpix 4300	D-AM			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
Coolpix 4500	D-N950			
Coolpix 4600	D-MM			
Coolpix 4800	D-AM			
Coolpix 5000	D-A			
Coolpix 5000	D-AX			
Coolpix 5000	D-CG1			
Coolpix 5200	D-AM			
Coolpix 5400	D-A			
Coolpix 5400	D-AX			
Coolpix 5400	D-CG1			
Coolpix 5600	D-MM			
Coolpix 5700	D-A			
Coolpix 5700	D-AX			
Coolpix 5900	D-MM			
Coolpix 600	D-CP2			
Coolpix 700	D-AM			
Coolpix 7600	D-MM			
Coolpix 775	D-MM			
Coolpix 7900	D-MM			
Coolpix 800				
Coolpix 8400	D-A			
Coolpix 8400	D-AX			
Coolpix 8400	D-CG3			
Coolpix 8700	D-A			
Coolpix 8700	D-AX			
Coolpix 880	D-MM			
Coolpix 8800	D-A			
Coolpix 8800	D-AX			
Coolpix 885	D-AM			
Coolpix 950	D-N950			
Coolpix 990	D-N950			
Coolpix 995	D-NC2			
Coolpix L1	D-MM			
Coolpix L10	D-SW			
Coolpix L101	D-MM			
Coolpix L11	D-SW			
Coolpix L12	D-SW			
Coolpix L14	D-SW			
Coolpix L15	D-SW			
Coolpix L16	D-SW			
Coolpix L18	D-SW			
Coolpix L2	D-SW			
Coolpix L3	D-SW			
Coolpix L4	D-SW			
Coolpix L5	D-MM			
Coolpix L6	D-SW			
Coolpix P1	D-MM			
Coolpix P2	D-MM			
Coolpix P3	D-SW			
Coolpix P4	D-SW			
Coolpix P50	D-CG6			
Coolpix P5000	D-A			
Coolpix P5000	D-AX			
Coolpix P5000	D-CG6			
Coolpix P5100	D-A			
Coolpix P5100	D-AX			
Coolpix P5100	D-CG6			
Coolpix P60	D-CG6			
Coolpix S1				
Coolpix S10				
Coolpix S2				
Coolpix S200	D-LI3			
Coolpix S210	D-LI3			
Coolpix S3				
Coolpix S4				
Coolpix S5				
Coolpix S500	D-LI2			
Coolpix S50c				
Coolpix S51				
Coolpix S510	D-LI2			
Coolpix S51c				

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
Coolpix S520	D-LI2			
Coolpix S550	D-LI2			
Coolpix S6	D-LI2			
Coolpix S6	D-SW			
Coolpix S600	D-LI2			
Coolpix S700	D-LI2			
Coolpix SQ				
D1	U-BXP			
D1	U-BXP100			
D100	U-AXP			
D100	U-AXP100			
D1H	U-BXP			
D1H	U-BXP100			
D1X	U-BXP			
D1X	U-BXP100			
D200	U-BXP			
D200	U-BXP100			
D2H	U-BXP			
D2H	U-BXP100			
D2HS	U-BXP			
D2HS	U-BXP100			
D2X	U-BXP			
D2X	U-BXP100			
D3	U-BXP			
D3	U-BXP100			
D300	U-BXP			
D300	U-BXP100			
D40	U-A			
D40	U-AX			
D40	U-AXP			
D40	U-AXP100			
D40	U-AZ			
D40x	U-A			
D40x	U-AX			
D40x	U-AXP			
D40x	U-AXP100			
D40x	U-AZ			
D50	U-A			
D50	U-AX			
D50	U-AXP			
D50	U-AXP100			
D50	U-AZ			
D60	U-A			
D60	U-AX			
D60	U-AXP			
D60	U-AXP100			
D60	U-AZ			
D70	U-A			
D70	U-AX			
D70	U-AXP			
D70	U-AXP100			
D70	U-AZ			
D70s	U-A			
D70s	U-AX			
D70s	U-AXP			
D70s	U-AXP100			
D70s	U-AZ			
D80	U-A			
D80	U-AX			
D80	U-AXP			
D80	U-AXP100			
D80	U-AZ			
E2	U-BXP			
E2	U-BXP100			
E2N	U-BXP			
E2N	U-BXP100			
E2Ns	U-BXP			
E2Ns	U-BXP100			
E2s	U-BXP			
E2s	U-BXP100			
E3	U-BXP			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
E3	U-BXP100			
E3s	U-BXP			
E3s	U-BXP100			

analog

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
F100	U-A			
F100	U-AX			
F100	U-AXP			
F100	U-AXP100			
F100	U-AZ			
F2	U-F			
F2	U-FGM			
F2	U-FX			
F2	U-FXP			
F3	U-F			
F3	U-FGM			
F3	U-FX			
F3	U-FXP			
F301	U-F			
F301	U-FGM			
F301	U-FX			
F301	U-FXP			
F3AF	U-AXP			
F4	U-AXP			
F401	U-A			
F401	U-AX			
F401	U-AXP			
F401	U-AXP100			
F401	U-AZ			
F401S	U-A			
F401S	U-AX			
F401S	U-AXP			
F401S	U-AXP100			
F401S	U-AZ			
F401X	U-A			
F401X	U-AX			
F401X	U-AXP			
F401X	U-AXP100			
F401X	U-AZ			
F5	U-AXP			
F50	U-A			
F50	U-AX			
F50	U-AXP			
F50	U-AXP100			
F50	U-AZ			
F501	U-A			
F501	U-AX			
F501	U-AXP			
F501	U-AXP100			
F501	U-AZ			
F55	U-A			
F55	U-AX			
F55	U-AXP			
F55	U-AXP100			
F55	U-AZ			
F6	U-AXP			
F60	U-A			
F60	U-AX			
F60	U-AXP			
F60	U-AXP100			
F60	U-AZ			
F601	U-A			
F601	U-AX			
F601	U-AXP			
F601	U-AXP100			
F601	U-AZ			
F601m	U-F			
F601m	U-FGM			
F601m	U-FX			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
F601m	U-FXP			
F65	U-A			
F65	U-AX			
F65	U-AXP			
F65	U-AXP100			
F65	U-AZ			
F70	U-A			
F70	U-AX			
F70	U-AXP			
F70	U-AXP100			
F70	U-AZ			
F75	U-A			
F75	U-AX			
F75	U-AXP			
F75	U-AXP100			
F75	U-AZ			
F80	U-A			
F80	U-AX			
F80	U-AXP			
F80	U-AXP100			
F80	U-AZ			
F801	U-A			
F801	U-AX			
F801	U-AXP			
F801	U-AXP100			
F801	U-AZ			
F801S	U-A			
F801S	U-AX			
F801S	U-AXP			
F801S	U-AXP100			
F801S	U-AZ			
F90	U-AXP			
F90X	U-AXP			
FA	U-F			
FA	U-FGM			
FA	U-FX			
FA	U-FXP			
FE	U-F			
FE	U-FGM			
FE	U-FX			
FE	U-FXP			
FE10	U-F			
FE10	U-FGM			
FE10	U-FX			
FE10	U-FXP			
FE2	U-F			
FE2	U-FGM			
FE2	U-FX			
FE2	U-FXP			
FG	U-F			
FG	U-FGM			
FG	U-FX			
FG	U-FXP			
FG-20	U-F			
FG-20	U-FGM			
FG-20	U-FX			
FG-20	U-FXP			
FM	U-F			
FM	U-FGM			
FM	U-FX			
FM	U-FXP			
FM10	U-F			
FM10	U-FGM			
FM10	U-FX			
FM10	U-FXP			
FM2	U-F			
FM2	U-FGM			
FM2	U-FX			
FM2	U-FXP			
FM2/T	U-F			
FM2/T	U-FGM			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update: 19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
FM2/T	U-FX			
FM2/T	U-FXP			
FM2N	U-F			
FM2N	U-FGM			
FM2N	U-FX			
FM2N	U-FXP			
FM3A	U-F			
FM3A	U-FGM			
FM3A	U-FX			
FM3A	U-FXP			
N2000	U-F			
N2000	U-FGM			
N2000	U-FX			
N2000	U-FXP			
N2020	U-A			
N2020	U-AX			
N2020	U-AXP			
N2020	U-AXP100			
N2020	U-AZ			
N4004	U-A			
N4004	U-AX			
N4004	U-AXP			
N4004	U-AXP100			
N4004	U-AZ			
N4004S	U-A			
N4004S	U-AX			
N4004S	U-AXP			
N4004S	U-AXP100			
N4004S	U-AZ			
N401X	U-A			
N401X	U-AX			
N401X	U-AXP			
N401X	U-AXP100			
N401X	U-AZ			
N50	U-A			
N50	U-AX			
N50	U-AXP			
N50	U-AXP100			
N50	U-AZ			
N55	U-A			
N55	U-AX			
N55	U-AXP			
N55	U-AXP100			
N55	U-AZ			
N60	U-A			
N60	U-AX			
N60	U-AXP			
N60	U-AXP100			
N60	U-AZ			
N6000	U-F			
N6000	U-FGM			
N6000	U-FX			
N6000	U-FXP			
N601	U-A			
N601	U-AX			
N601	U-AXP			
N601	U-AXP100			
N601	U-AZ			
N65	U-A			
N65	U-AX			
N65	U-AXP			
N65	U-AXP100			
N65	U-AZ			
N70	U-A			
N70	U-AX			
N70	U-AXP			
N70	U-AXP100			
N70	U-AZ			
N75	U-A			
N75	U-AX			
N75	U-AXP			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update: 19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
N75	U-AXP100			
N75	U-AZ			
N80	U-A			
N80	U-AX			
N80	U-AXP			
N80	U-AXP100			
N80	U-AZ			
N801	U-A			
N801	U-AX			
N801	U-AXP			
N801	U-AXP100			
N801	U-AZ			
N801S	U-A			
N801S	U-AX			
N801S	U-AXP			
N801S	U-AXP100			
N801S	U-AZ			
N90	U-AXP			
N90X	U-AXP			
Other 35 mm compact	U-AM			
Other 35 mm compact	U-AMZ			
Other 35 mm compact	U-MM			
Other APS compact	U-AM			
Other APS compact	U-AMZ			
Other APS compact	U-MM			
Pronea 600i	U-A			
Pronea 600i	U-AX			
Pronea 600i	U-AXP			
Pronea 600i	U-AXP100			
Pronea 600i	U-AZ			
Pronea 6i	U-A			
Pronea 6i	U-AX			
Pronea 6i	U-AXP			
Pronea 6i	U-AXP100			
Pronea 6i	U-AZ			
Pronea S	U-A			
Pronea S	U-AX			
Pronea S	U-AXP			
Pronea S	U-AXP100			
Pronea S	U-AZ			

Odys

all models

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
all models				

Olympus

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
AZ-2				
C-1	D-AM			
C-100	D-AM			
C-1000L	D-CAM			
C-120	D-AM			
C-1400L	D-CAM			
C-1400LX	D-CAM			
C-150	D-AM			
C-160	D-AM			
C-170	D-AM			
C-180	D-CP1			
C-2	D-MM			
C-200	D-AM			
C-2000	D-A			
C-2000	D-AX			
C-2000	D-CA2			
C-2020	D-A			
C-2020	D-AX			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
C-2020	D-CA2			
C-2030	D-A			
C-2030	D-AX			
C-2030	D-CA2			
C-2040	D-A			
C-2040	D-AX			
C-2040	D-CA2			
C-21	D-MM			
C-2100	D-CAM			
C 211				
C-220	D-AM			
C-2500L	D-CAM			
C-2500L	D-CAM			
C-300	D-AM			
C-300	D-MM			
C-3000	D-A			
C-3000	D-AX			
C-3000	D-CA2			
C-3020	D-A			
C-3020	D-AX			
C-3020	D-CA2			
C-3030	D-A			
C-3030	D-AX			
C-3030	D-CA2			
C-3040	D-A			
C-3040	D-AX			
C-3040	D-CA2			
C-310	D-AM			
C-310	D-MM			
C-315	D-CP1			
C-350	D-AM			
C-360	D-AM			
C-360	D-SW			
C-370	D-MM			
C-40	D-MM			
C-4000	D-A			
C-4000	D-AX			
C-4000	D-CA2			
C-4040	D-A			
C-4040	D-AX			
C-4040	D-CA2			
C-450	D-AM			
C-460	D-AM			
C-470	D-MM			
C-480	D-CP1			
C-50	D-MM			
C-500	D-AM			
C-5000	D-AM			
C-5050	D-A			
C-5050	D-AX			
C-5060	D-A			
C-5060	D-AX			
C-55	D-MM			
C-60	D-MM			
C-70	D-CP2			
C-700	D-A	C-A55		
C-7070	D-A			
C-720	D-A	C-A55		
C-725	D-A	C-A55		
C-730	D-A	C-A55		
C-740	D-A	C-A55		
C-750	D-A	C-A55		
C-760	D-A	C-A55		
C-765	D-A	C-A55		
C-770	D-A	C-A55		
C-8080	D-A			
C-8080	D-AX			
C-820L	D-AM			
C-830L	D-AM			
C-840L	D-AM			
C-860L	D-AM			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
C-920	D-AM			
C-960	D-AM			
C-990	D-AM			
D-360	D-AM			
D-390	D-AM			
D-395	D-AM			
D-450	D-AM			
D-460	D-AM			
D-490	D-AM			
D-500L	D-CAM			
D-540	D-CP1			
D-560	D-AM			
D-565	D-AM			
D-575	D-AM			
D-580	D-AM			
D-600L	D-CAM			
E-1	U-AXP			
E-1	U-AXP100			
E-100	U-AXP			
E-10D	U-AXP			
E-20P	U-AXP			
E-3	U-BXP			
E-3	U-BXP100			
E-300	U-A			
E-330	U-A			
E-400	U-A			
E-400	U-AX			
E-400	U-AXP			
E-400	U-AXP100			
E-400	U-AZ			
E-410	U-A			
E-410	U-AX			
E-410	U-AXP			
E-410	U-AXP100			
E-410	U-AZ			
E-500	U-A			
E-500	U-AX			
E-500	U-AXP			
E-500	U-AXP100			
E-500	U-AZ			
E-510	U-A			
E-510	U-AX			
E-510	U-AXP			
E-510	U-AXP100			
E-510	U-AZ			
FE-100	D-SW			
FE-110	D-SW			
FE-115	D-CP1			
FE-120	D-CP1			
FE-130	D-SW			
FE-140	D-SW			
FE-150	D-SW			
FE-160	D-SW			
FE-170	D-MM			
FE-180	D-MM			
FE-190	D-LI3			
FE-200	D-SW			
FE-210	D-SW			
FE-230	D-LI2			
FE-240	D-LI2			
FE-250	D-LI2			
FE-260	D-LI2			
FE-270	D-SW			
FE-280	D-LI2			
FE-290	D-SW			
FE-300	D-LI2			
FE-310	D-SW			
FE-340	D-LI2			
FE-350	D-LI2			
FE-5500	D-CP1			
MJU 1000	D-LI2			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
MJU 1010	D-LI2			
MJU 1020	D-LI2			
MJU 1030				
MJU 1200	D-LI2			
MJU 700	D-LI2			
MJU 720 SW				
MJU 725 SW				
MJU 730				
MJU 760	D-LI2			
MJU 770 SW				
MJU 780	D-LI2			
MJU 790 SW				
MJU 820	D-LI2			
MJU 830	D-LI2			
MJU 840	D-LI2			
MJU 850				
MJU Digital Series (not listed below)				
SP-310	D-MM			
SP-320	D-MM			
SP-350	D-MM			
SP-500 UZ	D-A	C-A55		
SP-510 UZ	D-A	C-A55		
SP-550 UZ	D-A	C-A55		
SP-560 UZ	D-A	C-A55		
SP-570 UZ	D-A	C-A55		
SP-700	D-MM			
Stylus 1000	D-LI2			
Stylus 1010	D-LI2			
Stylus 1020	D-LI2			
Stylus 1030				
Stylus 1200	D-LI2			
Stylus 300	D-MM			
Stylus 400	D-MM			
Stylus 410	D-MM			
Stylus 720				
Stylus 740	D-LI2			
Stylus 750	D-LI2			
Stylus 760	D-LI2			
Stylus 770				
Stylus 780	D-LI2			
Stylus 790				
Stylus 820	D-LI2			
Stylus 830	D-LI2			
Stylus 840	D-LI2			
Stylus 850				

analog

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
Mju-II	U-MJU			
Mju Series	U-AM			
Mju Series	U-AMZ			
Mju Series	U-MM			
OM-1	U-F			
OM-1	U-FGM			
OM-1	U-FX			
OM-1	U-FXP			
OM-10	U-F			
OM-10	U-FGM			
OM-10	U-FX			
OM-10	U-FXP			
OM-101	U-A			
OM-101	U-AX			
OM-101	U-AXP			
OM-101	U-AXP100			
OM-101	U-AZ			
OM-10 Quartz	U-F			
OM-10 Quartz	U-FGM			
OM-10 Quartz	U-FX			
OM-10 Quartz	U-FXP			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
OM-1MD	U-F			
OM-1MD	U-FGM			
OM-1MD	U-FX			
OM-1MD	U-FXP			
OM-1n	U-F			
OM-1n	U-FGM			
OM-1n	U-FX			
OM-1n	U-FXP			
OM-2	U-F			
OM-2	U-FGM			
OM-2	U-FX			
OM-2	U-FXP			
OM-20	U-F			
OM-20	U-FGM			
OM-20	U-FX			
OM-20	U-FXP			
OM2000	U-F			
OM2000	U-FGM			
OM2000	U-FX			
OM2000	U-FXP			
OM-2n	U-F			
OM-2n	U-FGM			
OM-2n	U-FX			
OM-2n	U-FXP			
OM-2S	U-F			
OM-2S	U-FGM			
OM-2S	U-FX			
OM-2S	U-FXP			
OM-2SP	U-F			
OM-2SP	U-FGM			
OM-2SP	U-FX			
OM-2SP	U-FXP			
OM-3	U-F			
OM-3	U-FGM			
OM-3	U-FX			
OM-3	U-FXP			
OM-30	U-F			
OM-30	U-FGM			
OM-30	U-FX			
OM-30	U-FXP			
OM-3T	U-F			
OM-3T	U-FGM			
OM-3T	U-FX			
OM-3T	U-FXP			
OM-3Ti	U-F			
OM-3Ti	U-FGM			
OM-3Ti	U-FX			
OM-3Ti	U-FXP			
OM-4	U-F			
OM-4	U-FGM			
OM-4	U-FX			
OM-4	U-FXP			
OM-40	U-F			
OM-40	U-FGM			
OM-40	U-FX			
OM-40	U-FXP			
OM-4T	U-F			
OM-4T	U-FGM			
OM-4T	U-FX			
OM-4T	U-FXP			
OM-4Ti	U-F			
OM-4Ti	U-FGM			
OM-4Ti	U-FX			
OM-4Ti	U-FXP			
OM-707	U-A			
OM-707	U-AX			
OM-707	U-AXP			
OM-707	U-AXP100			
OM-707	U-AZ			
OM-77	U-A			
OM-77	U-AX			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
OM-77	U-AXP			
OM-77	U-AXP100			
OM-77	U-AZ			
OM-88	U-A			
OM-88	U-AX			
OM-88	U-AXP			
OM-88	U-AXP100			
OM-88	U-AZ			
OM-F	U-F			
OM-F	U-FGM			
OM-F	U-FX			
OM-F	U-FXP			
OM-G	U-F			
OM-G	U-FGM			
OM-G	U-FX			
OM-G	U-FXP			
OM-PC	U-F			
OM-PC	U-FGM			
OM-PC	U-FX			
OM-PC	U-FXP			
Other 35 mm compact	U-AM			
Other 35 mm compact	U-AMZ			
Other 35 mm compact	U-MM			
Other APS compact	U-AM			
Other APS compact	U-AMZ			
Other APS compact	U-MM			

Panasonic

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
DMC-F 1				
DMC-FX01	D-SW			
DMC-FX07	D-SW			
DMC-FX1	D-CP1			
DMC-FX10	D-SW			
DMC-FX100	D-LI2			
DMC-FX12	D-SW			
DMC-FX2	D-CP1			
DMC-FX3	D-SW			
DMC-FX30	D-SW			
DMC-FX33	D-LI2			
DMC-FX5	D-LI2			
DMC-FX50	D-LI2			
DMC-FX55	D-LI2			
DMC-FX7	D-LI2			
DMC-FX8	D-LI2			
DMC-FX9	D-LI2			
DMC-FZ1	D-A	C-A55		
DMC-FZ10	D-A	C-A62		
DMC-FZ10	D-AX	C-A62		
DMC-FZ15	D-A	C-A62		
DMC-FZ15	D-AX	C-A62		
DMC-FZ18	D-A	C-A55		
DMC-FZ2	D-A	C-A55		
DMC-FZ20	D-A	C-A62		
DMC-FZ20	D-AX	C-A62		
DMC-FZ3	D-A	C-A55		
DMC-FZ30	D-A	C-A55		
DMC-FZ30	D-AX	C-A55		
DMC-FZ4	D-A	C-A55		
DMC-FZ5	D-A	C-A55		
DMC-FZ50	D-A	C-A55		
DMC-FZ50	D-AX	C-A55		
DMC-FZ7	D-A	C-A55		
DMC-FZ8	D-A	C-A55		
DMC-L1	U-F			
DMC-L1	U-FGM			
DMC-L1	U-FX			
DMC-L1	U-FXP			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update: 19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
DMC-L10	U-A			
DMC-L10	U-AX			
DMC-L10	U-AXP			
DMC-L10	U-AXP100			
DMC-L10	U-AZ			
DMC-LC1	U-F			
DMC-LC1	U-FGM			
DMC-LC1	U-FX			
DMC-LC1	U-FXP			
DMC-LC20	D-MM			
DMC-LC33	D-MM			
DMC-LC40	D-MM			
DMC-LC43	D-MM			
DMC-LC5				
DMC-LC50	D-MM			
DMC-LC70	D-MM			
DMC-LC80	D-MM			
DMC-LS1	D-MM			
DMC-LS3	D-CP2			
DMC-LS60	D-SW			
DMC-LS75	D-SW			
DMC-LX1	D-SC			
DMC-LX2	D-SC			
DMC-LZ1	D-MM			
DMC-LZ2	D-MM			
DMC-LZ3	D-MM			
DMC-LZ5	D-MM			
DMC-LZ6	D-MM			
DMC-LZ7	D-MM			
DMC-TZ1	D-CP2			
DMC-TZ2	D-CP2			
DMC-TZ3	D-CP2			

Pentacoon

all models

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
all models				

Pentax

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
*istD	U-AXP			
*istD	U-AXP100			
*istDL	U-A			
*istDL	U-AX			
*istDL	U-AXP			
*istDL	U-AXP100			
*istDL	U-AZ			
*istDL2	U-A			
*istDL2	U-AX			
*istDL2	U-AXP			
*istDL2	U-AXP100			
*istDL2	U-AZ			
*istDs	U-A			
*istDs	U-AX			
*istDs	U-AXP			
*istDs	U-AXP100			
*istDs	U-AZ			
Digibino				
K 100 D	U-A			
K 100 D	U-AX			
K 100 D	U-AXP			
K 100 D	U-AXP100			
K 100 D	U-AZ			
K 10 D	U-A			
K 10 D	U-AX			
K 10 D	U-AXP			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
K 10 D	U-AXP100			
K 10 D	U-AZ			
K 110 D	U-A			
K 110 D	U-AX			
K 110 D	U-AXP			
K 110 D	U-AXP100			
K 110 D	U-AZ			
K 200 D	U-A			
K 200 D	U-AX			
K 200 D	U-AXP			
K 200 D	U-AXP100			
K 200 D	U-AZ			
K 20 D	U-A			
K 20 D	U-AX			
K 20 D	U-AXP			
K 20 D	U-AXP100			
K 20 D	U-AZ			
Optio 30	D-MM			
Optio 33	D-MM			
Optio 330	D-MM			
Optio 33WR				
Optio 430	D-MM			
Optio 50				
Optio 550	D-MM			
Optio 555	D-MM			
Optio 60				
Optio 750z	D-MM			
Optio A10	D-LI2			
Optio A20	D-LI2			
Optio A30	D-MM			
Optio A40	D-LI2			
Optio E10				
Optio E20	D-SW			
Optio E30	D-MM			
Optio E40	D-MM			
Optio E50	D-MM			
Optio L20	D-LI2			
Optio L40	D-LI2			
Optio M10	D-LI2			
Optio M20	D-LI2			
Optio M30	D-SW			
Optio M40	D-SW			
Optio M50	D-CP2			
Optio MX				
Optio S10	D-LI2			
Optio S12	D-LI2			
Optio S30	D-MM			
Optio S4	D-LI2			
Optio S40	D-LI2			
Optio S45	D-LI2			
Optio S50	D-LI2			
Optio S52	D-LI2			
Optio S55	D-LI2			
Optio S55	D-LI2			
Optio S5i	D-LI2			
Optio S6	D-LI2			
Optio S60	D-LI2			
Optio S7	D-LI2			
Optio SV	D-LI2			
Optio T10	D-LI2			
Optio T20	D-SW			
Optio T30	D-SW			
Optio V10	D-MM			
Optio W10	D-MM			
Optio W20	D-MM			
Optio WP	D-MM			
Optio WPi	D-MM			
Optio X	D-CP2			
Optio Z10	D-MM			
W30	D-MM			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update: 19.03.08

analog

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
Other 35 mm compact	U-AM			
Other 35 mm compact	U-AMZ			
Other 35 mm compact	U-MM			
Other APS compact	U-AM			
Other APS compact	U-AMZ			
Other APS compact	U-MM			

Ricoh

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
Caplio	D-AM			
Caplio G3	D-CP1			
Caplio G4	D-CP2			
Caplio GR digital	D-CP1			
Caplio GX	D-CP2			
Caplio GX8	D-CP2			
Caplio R1	D-CP2			
Caplio R2	D-CP2			
Caplio R3	D-LI2			
Caplio R30	D-LI2			
Caplio R4	D-LI2			
Caplio R40	D-LI2			
Caplio R5	D-LI2			
Caplio RX	D-CP1			
Caplio RZ1	D-CP1			
Digimax130	D-AM			
Digimax201	D-MM			
Digimax240	D-AM			
Digimax360	D-AM			
Digimax420	D-AM			
DigimaxV3	D-MM			
DigimaxV4	D-CP1			
DigimaxV4	D-MM			
GX100	D-CP2			
R6	D-LI2			
RDC 2				
RDC 300				
RDC 4200				
RDC 4300				
RDC 500				
RDC 5300				
RDC-6000	D-AM			
RDC 7				
RDC 700				
RR 1				
RR 10				
RR120	D-AM			
RR211	D-MM			
RR230	D-AM			
RR30	D-CP1			
RR330	D-AM			
RR530	D-LI2			
RR630	D-LI2			
RR660	D-LI2			
RR730	D-LI2			

Rollei

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
da 10	D-MM			
da 3	D-MM			
da 4	D-MM			
da 5	D-MM			
da 5324	D-LI2			
da 6	D-MM			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
da 6324	D-LI2			
da 8324	D-LI2			
db 60	D-MM			
dp 5200	D-MM			
dp 5500	D-MM			
dp 6000	D-MM			
dp 6200	D-LI2			
dp 6300	D-CG3			
dp 6500	D-MM			
dp 8300	D-MM			
dp 8300	D-MM			
dp 8500	D-MM			
dr 4	D-CP1			
dr 5	D-CP1			
dr 5100	D-CP1			
ds 6	D-LI2			
dt 3200	D-MM			
dt 4200	D-MM			
dt 6 Tribute	D-MM			
dx 63	D-MM			

Samsung

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
D 60	D-SW			
D 70	D-SW			
Digimax 101	D-MM			
Digimax 130	D-AM			
Digimax 201	D-MM			
Digimax 202	D-MM			
Digimax 240	D-AM			
Digimax 250	D-MM			
Digimax 301	D-MM			
Digimax 360	D-AM			
Digimax 370	D-CP1			
Digimax 401	D-MM			
Digimax 420	D-AM			
Digimax 430	D-CP1			
Digimax 530	D-CP1			
Digimax A4	D-CP2			
Digimax A40	D-CP1			
Digimax A400	D-CP1			
Digimax A402	D-CP1			
Digimax A5	D-CP2			
Digimax A50	D-CP2			
Digimax A55	D-CP2			
Digimax A6	D-CP2			
Digimax A7	D-CP2			
Digimax Pro815	D-A			
Digimax Pro815	D-AX			
Digimax UCA 3	D-MM			
Digimax UCA 5	D-CP2			
Digimax UCA 505	D-CP1			
Digimax V 3	D-MM			
Digimax V 4	D-CP1			
Digimax V 4	D-MM			
Digimax V 40	D-CP1			
Digimax V 5	D-CP1			
Digimax V 50	D-CP1			
Digimax V 6	D-CP2			
Digimax V 70	D-CP2			
Digimax V 700	D-CP2			
Digimax V 800	D-CP2			
GX-10	U-AXP			
GX- 1L	U-AXP			
GX- 1S	U-AXP			
GX-20	U-A			
GX-20	U-AX			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
GX-20	U-AXP			
GX-20	U-AXP100			
GX-20	U-AZ			
i100				
i 6 PMP				
i 7				
i 70				
i 8				
i 80				
i 85				
L100	D-LI2			
L110	D-LI2			
L210	D-MM			
L 50	D-LI2			
L 55W	D-CP1			
L 60	D-LI2			
L 70	D-LI3			
L700	D-LI2			
L 73	D-LI2			
L730	D-LI2			
L 74				
L 74 w	D-SW			
L 77	D-LI2			
L 80	D-SW			
L830	D-LI2			
L 83 T				
L 85	D-CP2			
NV 10	D-LI2			
NV 11	D-SW			
NV 15	D-LI2			
NV 20	D-LI2			
NV 24	D-LI2			
NV 3				
NV 30	D-LI2			
NV 4				
NV 40	D-LI2			
NV 7				
NV 70				
NV 7 OPS				
NV 8	D-LI2			
other i-Series not listed				
S1000	D-SW			
S1050	D-CP2			
S1060	D-SW			
S 500	D-MM			
S 600	D-MM			
S 630				
S 700	D-SW			
S 730				
S 760	D-SW			
S 800	D-SW			
S 85	D-MM			
S 850	D-SW			
S 860	D-SW			

Sanyo

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
E60				
E7	D-LI2			
S60	D-SW			
S7	D-SW			
VPC-60	D-LI2			
VPC-AZ 3	D-CP2			
VPC-E10	D-CP2			
VPC-E60 EX				
VPC-E7 EX	D-LI2			
VPC-J 1	D-MM			
VPC-J 2	D-MM			

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
VPC-J4	D-MM			
VPC-MZ 3	D-CP1			
VPC-S1	D-MM			
VPC-S3	D-MM			
VPC-S4	D-MM			
VPC-S5	D-MM			
VPC-S50	D-SW			
VPC-S6	D-LI2			
VPC-S60	D-SW			
VPC-S7	D-LI2			
VPC-S70	D-SW			
VPC-S760	D-SW			
VPC-SX500	D-MM			
VPC-SX550	D-MM			
VPC-X360	D-AM			

Sigma

digital

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
DP1	D-MM			
SD 10	U-BXP			
SD 10	U-BXP100			
SD 14	U-BXP			
SD 14	U-BXP100			
SD 9	U-BXP			
SD 9	U-BXP100			

analog

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
SA-7	U-A			
SA-7	U-AX			
SA-7	U-AXP			
SA-7	U-AXP100			
SA-7	U-AZ			
SA-9	U-A			
SA-9	U-AX			
SA-9	U-AXP			
SA-9	U-AXP100			
SA-9	U-AZ			

Sinar

all models

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
all models				

Sony

digital

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
DSC-780	D-MM			
DSC-D770	U-AXP	C-A62		
DSC-F1	D-MAV			
DSC-F505	D-A			
DSC-F707	D-A			
DSC-F717	D-A			
DSC-F77				
DSC-F828	D-A			
DSC-F88				
DSC-FX 77				
DSC-G1				
DSC-H1	D-A	C-A58		
DSC-H1	D-AX	C-A58		
DSC-H10	D-A			
DSC-H2	D-A	C-A58		
DSC-H2	D-AX	C-A58		

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
DSC-H3	D-A	C-A58		
DSC-H5	D-A	C-A58		
DSC-H5	D-AX	C-A58		
DSC-H50	D-A			
DSC-H7	D-A			
DSC-H9	D-A			
DSC-L1	D-CP1			
DSC-N1	D-LI2			
DSC-N2	D-LI2			
DSC-P1	D-CP1			
DSC-P10	D-CP2			
DSC-P100	D-CP1			
DSC-P12	D-CP2			
DSC-P120	D-CP1			
DSC-P150	D-CP2			
DSC-P2	D-CP1			
DSC-P200	D-CP2			
DSC-P31	D-CP1			
DSC-P43	D-MM			
DSC-P5	D-CP1			
DSC-P50	D-CP1			
DSC-P51	D-CP1			
DSC-P52	D-CP1			
DSC-P7	D-CP1			
DSC-P71	D-CP1			
DSC-P72	D-CP2			
DSC-P73	D-CP2			
DSC-P8	D-CP2			
DSC-P9	D-CP1			
DSC-P92	D-CP2			
DSC-P93	D-CP2			
DSC-R1				
DSC-S30				
DSC-S40	D-CP1			
DSC-S50				
DSC-S500	D-SW			
DSC-S55				
DSC-S60	D-MM			
DSC-S650	D-CP1			
DSC-S70	D-A			
DSC-S70	D-AX			
DSC-S70	D-CG1			
DSC-S730	D-MM			
DSC-S75	D-A			
DSC-S75	D-AX			
DSC-S75	D-CG1			
DSC-S750	D-CP2			
DSC-S80	D-MM			
DSC-S800	D-CP2			
DSC-S85	D-A			
DSC-S85	D-AX			
DSC-S85	D-CG1			
DSC-S90	D-MM			
DSC-T1				
DSC-T10				
DSC-T100				
DSC-T 2				
DSC-T20				
DSC-T200				
DSC-T3				
DSC-T30				
DSC-T300				
DSC-T33				
DSC-T5				
DSC-T50				
DSC-T7				
DSC-T 70				
DSC-T9				
DSC-U20				
DSC-U30				
DSC-U40				

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use

CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer

Date of last update:19.03.08

Camera	Housing	CA-Adapter	RA-Adapter	Ext-Adapter
DSC-U50				
DSC-U60				
DSC-U Series				
DSC-V1	D-SC			
DSC-V3	D-CG3			
DSC-W1	D-SW			
DSC-W100	D-LI2			
DSC-W110	D-LI2			
DSC-W12	D-SW			
DSC-W120	D-LI2			
DSC-W130	D-LI2			
DSC-W150	D-LI2			
DSC-W170	D-LI2			
DSC-W200	D-LI2			
DSC-W30	D-SW			
DSC-W300	D-SW			
DSC-W35	D-SW			
DSC-W5	D-SW			
DSC-W50	D-LI2			
DSC-W55	D-LI2			
DSC-W7	D-SW			
DSC-W70	D-LI2			
DSC-W80	D-LI2			
DSC-W90	D-LI2			
DSLR-A 100	U-A			
DSLR-A 100	U-AX			
DSLR-A 100	U-AXP			
DSLR-A 100	U-AXP100			
DSLR-A 100	U-AZ			
DSLR-A 200	U-A			
DSLR-A 200	U-AX			
DSLR-A 200	U-AXP			
DSLR-A 200	U-AXP100			
DSLR-A 200	U-AZ			
DSLR-A 300	U-A			
DSLR-A 300	U-AX			
DSLR-A 300	U-AXP			
DSLR-A 300	U-AXP100			
DSLR-A 300	U-AZ			
DSLR-A 350	U-A			
DSLR-A 350	U-AX			
DSLR-A 350	U-AXP			
DSLR-A 350	U-AXP100			
DSLR-A 350	U-AZ			
DSLR-A 700	U-BXP			
DSLR-A 700	U-BXP100			
MVC-CD 1000	D-A			
MVC-CD 1000	D-AX			
MVC-CD 200	D-A			
MVC-CD 200	D-AX			
MVC-CD 300	D-A			
MVC-CD 300	D-AX			
MVC-CD 350				
MVC-CD 400	D-A			
MVC-CD 400	D-AX			
MVC-CD 500	D-A			
MVC-CD 500	D-AX			
MVC-F 77				
MVC-FD200				
MVC-FD5	D-MAV			
MVC-FD7	D-MAV			
MVC-FD71	D-MAV			
MVC-FD73	D-MAV			
MVC-FD75	D-MAV			
MVC-FD83	D-MAV			
MVC-FD85	D-MAV			
MVC-FD88	D-MAV			
MVC-FD90				
MVC-FD91				
MVC-FD95				
MVC-FX 77				

Housings for Photographic Cameras

multiple housings indicate, that housings may differ according to application and use
 CA-, RA- and Ext-Adapters will have to be purchased in addition to the housing from your local dealer
 Date of last update:19.03.08

Toshiba

digital

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
PDR-2300	D-AM			
PDR-3300s	D-AM			
PDR-3320	D-MM			
PDR-4300	D-AM			
PDR-5300	D-MM			
PDR-M 25	D-MM			
PDR-M3310	D-MM			
PDR-M 500				
PDR-M 70	D-MM			
PDR-M 700				
PDR-M 71	D-MM			
PDR-M 81	D-MM			
PDR-T10				
PDR-T20	D-CP1			
PDR-T30	D-CP1			

Vivitar

all models

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
all models				

Yakumo

all models

<i>Camera</i>	<i>Housing</i>	<i>CA-Adapter</i>	<i>RA-Adapter</i>	<i>Ext-Adapter</i>
all models				